



Item number 1999910122




## Disposable gloves, THOR Power Grip, S, black, nitrile, powder-free

✓ Great protection, high level of comfort, power grip

CAT  
III

### Product Description

THOR Power Grip provides great protection combined with good comfort. The nitrile glove is particularly suitable for chemical splashes due to the glove's thickness which does not compromise penetration. The glove is particularly suitable for: pharma, the food industry, the automotive industry and cleaning with a rolled edge.

HIGH  
GRIPAQL  
1.5EN  
420

### Specifications

|                                                                                        |                                                                                             |
|----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| Base name                                                                              | Disposable gloves                                                                           |
| Brand                                                                                  | THOR                                                                                        |
| Sub-brand                                                                              | Power Grip                                                                                  |
| Size                                                                                   | S                                                                                           |
| Color                                                                                  | Black                                                                                       |
| Properties                                                                             | Rolled cuff                                                                                 |
| Features                                                                               | Powder-free                                                                                 |
| Single or multiple use                                                                 | Single use                                                                                  |
| Material                                                                               | Nitrile                                                                                     |
| Length/depth                                                                           | 240 mm                                                                                      |
| Width                                                                                  | 85 mm                                                                                       |
| Weight, net                                                                            | 5.7 g                                                                                       |
| Thickness                                                                              | Min. 0,15 mm                                                                                |
| Certifications                                                                         | CAT III, CE, Food contact materials                                                         |
| CE Category (Personal Protective Equipment)                                            | CAT III                                                                                     |
| Product or test standards                                                              | AQL 1.5, EN 16523, EN 374-1:2016 Type B KPT, EN 374-2, EN 374-4:2013, EN 374-5:2016, EN 420 |
| Directives, regulations and acts                                                       | (EU) 2016/425, (EC) No 1935/2004, BEK nr 681 af 25/05/2020, (EC) No 2023/2006               |
| Because of the products composition it has an expiry date from the production date on: | 5 years                                                                                     |
| Storage Instructions                                                                   | Store dry, room temperature and no direct sunlight.                                         |
| Product Disposal Instructions                                                          | Can be disposed of with normal household waste sorted according to local regulations.       |
| Packaging Disposal Instructions                                                        | To be recycled or incinerated.                                                              |

Packaging data

| Unit | Contains | Length  | Width   | Height  | EAN           |
|------|----------|---------|---------|---------|---------------|
| cII  | 10 pck   | 37.4 cm | 26.4 cm | 25.6 cm | 5703538471339 |
| pck  | 50 pcs   | 25.3 cm | 12.7 cm | 7.4 cm  | 5703538471322 |



The CE mark guarantees that a product is safe to use and complies with all safety precautions. CE stands for *Conformité Européenne* (European Conformity) and is mainly found on electronic equipment, safety equipment, construction products, and medical devices.



The glass-fork-symbol guarantees that products live up to the demands stated in the European legislation for food contact materials. The symbol is not mandatory but advised on products used for food contact.



Third-party type approval is required for all Category III personal protective equipment (PPE) products. CAT III products will be accompanied by a notified body number for the 3rd party verification of the product's safety.



The product does not contain latex.



The glove has a finger textured surface.



The glove has a high grip.



The glove is 240 mm long.



The standard specifies the requirements for protective gloves against chemicals and microorganisms. Type B has been tested for a permeation time of at least 30 minutes with the chemicals sodium hydroxide 40%, hydrogen peroxide 30% and formaldehyde 37%.



The standard specifies the requirements for protective gloves against hazardous chemicals and microorganisms. This part of the standard describes the glove's resistance to bacteria and fungi, but to viruses.



The standard specifies a method for testing gloves to determine whether the glove provides resistance to the permeation of chemicals and/or microorganisms. The test consists of an air and water test to identify leaks in the glove. They follow the ISO 2859 sampling plan. Not all gloves can be tested with air. In this case a water test is used.



The standard specifies the requirements for protective gloves in relation to general requirements and test methods.

